

- | | |
|----------------------------------|----------------------------|
| 1. Connection Port (DSPB-K) – J4 | 6. RCA Out Sub – J10 |
| 2. RCA Out Left – J9 | 7. Audio Input Header – J3 |
| 3. 3.5mm Output – J7 | 8. RCA Input Right – J5 |
| 4. RCA Out Right – J6 | 9. 3.5mm Input – J1 |
| 5. Audio Output Header – J8 | 10. RCA Input Left – J2 |

